


STUCCO EXPANSION JOINTS

Corner Expansion Joint Outside

(3-Piece) is designed to relieve stress in stucco at outside corners where excess movement or shrinkage might result in cracked stucco.


Product No.	Ground "A"	Box Count
AMXJO-380	3/8"	15
AMXJO-500	1/2"	15
AMXJO-580	5/8"	15
AMXJO-750	3/4"	15
AMXJO-780	7/8"	12



Corner Expansion Joint Inside

(3-Piece) is designed to relieve stress in stucco at inside corners where excess movement or shrinkage might result in cracked stucco.

Product No.	Ground "A"	Box Count
AMXJI-380	3/8"	15
AMXJI-500	1/2"	15
AMXJI-580	5/8"	15
AMXJI-750	3/4"	15
AMXJI-780	7/8"	15



NOTE: All joints should be embedded in sealant and sealed after installation if necessary.